





EXPLODED PARTS DIAGRAMS

Assembly Steps

1. Diff. Gear Assembly




2. Diff Case/ Driveshaft Assembly






3. Motor Assembly






4. Front Shock Tower Assembly





5. Rear Shock Tower Assembly




6. Front Bumper Assembly






7. Rear Bumper Assembly




8. Front Drive Assembly






9. Shock Assembly




10. Steering Assembly






11. Front Support Plates Assembly




12. Wheels Assembly






13. Servo /Electrical Parts Assembly





14. ESC cover/Battery Assembly









15. Body Assembly.






PARTS LISTING

FTX10500  Chassis / Battery brace	FTX10501  Upper Sway Arm(F/R)	FTX10502  ESC Cover	FTX10503  Front Holder	FTX10504  Gear Cover
FTX10505  Gearbox Housing	FTX10506  Shock Tower	FTX10507  Shock Mount	FTX10509  Front Lower Sway Bar	FTX10510  Rear Lower Sway Bar
FTX10511  Rear Hub Carrier	FTX10512  Steering knuckle arms	FTX10513  Caster Block (R/L)	FTX10514  Steering Links Set	FTX10515  Steering Mount Set / Steering horn
FTX10558  Servo Mount	FTX10559  Motor Mount	FTX10517  Wheel Hex w/Pins	FTX10518  Diff. Case	FTX10519  Diff Gasket & O Ring
FTX10520  Main Spur gear (58T)	FTX10521  Diff Crown Gear (42T)	FTX10522  Diff Bevel Gear Set	FTX10523  Diff. Case	FTX10524  Diff Output Cups
FTX10525  Drive Gear(17T)	FTX10526  Drive Output cups	FTX10527  Central Driveshaft	FTX10528  Front CVD Drive shaft	FTX10529  Rear shaft
FTX10530  Driveshaft	FTX10531  Centre Drive Output Cups	FTX10532  Wheel axle	FTX10533  Upper Link Turnbuckles (F/R)	FTX10534  Pin-3*54
FTX10535  Pin-3*54	FTX10536  Pin-4*40	FTX10537  Pin-3*28	FTX10538  Pin-3*23	FTX10539  Pin-3*23



FTX10538  Pin-3*28	FTX10539  Pin-3*23	FTX10540  Pin-2.5*22	FTX10541  Pin-2*10	FTX10542  Steering Saver Tube & Spring Set (metal)
FTX10543  Shock Absorber	FTX10544  Shock Pivot Ball (upper)	FTX10545  Shock Pivot Ball (lower)	FTBB31  Ball Bearing $\phi 4 * \phi 7 * 2.5$	FTBB10  Ball Bearing $\phi 10 * \phi 15 * 4$
FTBB120  Ball Bearing $\phi 5 * \phi 10 * 4$	FTX10546  Ball Head Screw $\phi 4.8 * 5$	FTX10547  Ball Head Screw $\phi 4.8 * 7$	FTX10548  Ball Head Screw $\phi 6.8 * 6$	FTX10549  Ball Head Screw $\phi 6.8 * 8$
FTX10570  Front Wheel Complete	FTX10571  Rear Wheel Complete	FTX10572  Drift Wheel Complete	FTX10573  Front Wheel Rim	FTX10574  Rear Wheel Rim
FTX10575  Front Tire W / Foam	FTX10576  Rear Tire W / Foam	FTX10550  Bumper Foam	FTM4BKF  Flange Nut M4	FTX10580  E-Clips $\phi 4.0\text{mm}$
FAST122  Grub Hex Screw 3*3	FTX-SBH043  Button Head 3*8	FTX-SBH044  Button Head 3*10	FTX-SBH045  Button Head 3*12	FTX-SBH046  Button Head 3*14
FTX-SBH051  Button Head 3*23	FTX-SCH004  Column Head 2*8	FTX-SBH043  Flat Head 2.5*10	FTX-SFH044  Flat Head 3*10	FTX-SBH003  Button Head 2*6



FTX10579



Body Accessories

FTX6550




Body Clip Ø1.2mm

FTX10577R
FTX10577BK



PC Body(Assembled)

FTX10578Clear
FTX10578R
FTX10578BK




PC Body/Stickers

FTX10557 (Brushed)



Motor(RC550-8517)

ET0018 (Brushed)



Servo-9KG

FTX10556 (Brushed)



(without Gyro)
Radio/Receiver

FTX10556R (Brushed)



(without Gyro)
DVC Receiver

FTX10584 (Brushed)




WP1040 Speed Control

FTX10552 (Brushless)



Brushless Motor 3300kv

ET2069



Servo-15KG

FTX10554 (Brushless)




Radio/Receiver

FTX10554-R (Brushless)




Ftx Stinger Receiver Only

FTX10553 (Brushless)




ESC Brushless-60A

FTX10583 (Brushed)



Light

FTX10567



Light Control Box

FTX10568



Sway Bar + Links

OPTIONAL UPGRADABLE PARTS

FTX10590



Motor Mount(AL.)

FTX10591



Motor Gear (23T/29T)

FTX10592



Rear Axle Mount(AL.)

FTX10593



Steering Mount(AL.)

FTX10594



Caster Block(AL.)

FTX10596



Aluminium Shock
Absorber Set